

WALL PAD SYSTEM ASSY.

WALL PAD INSTALLATION

STEP 1: Draw or strike a chalk line on the wall 4" to 6" up from the floor. This height will prevent dirt from accumulating under the mat.

STEP 2: Line up the "J" channel with the bottom edge on the line as shown below. Drill and anchor the channel to the wall with an appropriate fastener. Spacing and type of fastener is dependant on the type of wall structure. A groove is provided in the channel to aid in drilling holes.

STEP 3: Measure up from the bottom line the height of the pad less 2 V2" and make another line parallel to the bottom line.

STEP 4: Locate the "Z" channel on the top line as shown and anchor to the wall as was done with the "J" channel on the bottom.

STEP 6: Slip the "J" channel over the pads as shown and secure it down in the "Z" channel.

DIST. SEE BELOW

4" - 6"

Distance of most common sizes:

If pad is:	Then distance"
5ft.	57 1/2"
6ft.	69 1/2"
7ft.	81 1/2"

STEP 5: Slide each pad section into the bottom channel completely and butting up against each other.